





Chrome pieces on the back slide into the black pieces on the recliner and click into place

