

WOODEN PLATFORM BED FRAME

ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.

Injury may result from tipping furniture. You must install the Tipping Restraint Hardware with the unit to prevent the unit from tipping and causing any accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

This tipping restraint is not an earthquake restraint. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.

Serious or fatal crushing injuries can occur from furniture tipping over. To prevent furniture from tipping over it must be permanently fixed to the wall. Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home

Failure to detach this restraint before moving furniture may result in injury or damage.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Customer Service Email: CustomerExperience@belnick.com | Phone: 866-552-2810

YKC-1090-K-WAL-GG / YKC-1090-K-NAT-GG



Congratulations!

You just purchased a piece of happiness. At Belnick, we believe you can transform your spaces into the most inspired places with furnishings that are the perfect combination of form, function and style. As original innovators of online furniture retail, we offer the best selection of popular, contemporary styles at cool, comfortable prices. And, with decades of proven shipping and packaging expertise, our Extended Quality Checklist ensures a rewarding, hassle-free experience time and time again. It's just what you need to bring your vision to life.

Thank you & Enjoy!!

your friends at Belnick



LIKE IT!

*Share it on social
& Tell a friend!
#Spaces2Places*



LOVE IT!

*Write an online
product review
where purchased*



NOT SURE?

*Let us help!
Contact our
customer support.*

Have a question, concern or simply need a hand? Your satisfaction is our top priority. Contact us at 866-552-2810 or customerexperience@belnick.com. We're here to help!

Browse Our Branded Collections

There's something for everyone inside our family of brands.



MERRICK | LANE

Emma+Oliver®

TAYLOR + LOGAN

BlackArc®



Visit www.belnick.com/brands or scan this code to go even faster!

BELNICK

ONE VISION. ENDLESS POSSIBILITIES.



We pride ourselves on providing an excellent customer experience starting right here with your package and instructions. Everything you need should be right where you need it, so you can get to enjoying your new item ASAP. But despite our best efforts, sometimes "slips happen." If you need any support, from replacement parts to recommendations, please reach out to our wonderful customer support team at 866-552-2810 or customerexperience@belnick.com. We're here to help!

EVERY BELNICK PRODUCT




Quality &
Durability Tested



Packaged
with Care



Shipped from
our U.S. Facility



Designed
for Easy
Assembly




Ethically
Sourced

Please visit <https://www.belnick.com/warranty> for complete warranty information.

Read this manual before using this product. Failure to follow the instructions and safety precautions in this manual can result in serious injury or death. Keep this manual in a safe location for future reference.


Part

Part 1: Left & Right Siderails




2pcs

Part 2: Headboard & Footboard




2pcs

Part 3: Left Headboard & Right Footboard Legs



2pcs

Part 4: Right Headboard & Left Footboard Legs



2pcs

Part 5: Left & Right Side Legs




2pcs

Part 6: Center Legs




6pcs

Part 7: Center Rail




2pcs

Part 8: Support Slats



1pc

Hardware



M8 - 85mm Screw

Part A x 16pcs




M6 - 50mm Screw

Part B x 6pcs




M6 - 30mm Screw

Part C x 4pcs



M8 - 1mm Large Lock Washer

Part D x 16pcs



M8 - 1mm Large Flat Washer

Part E x 16pcs




M5 Allen Wrench

Part H x 1pcs




M4 Allen Wrench

Part I x 1pcs




30mm Self-Tapping Screw

Part J x 10 pcs



M6 - 1mm Small Lock Washer


Part F x 4pcs



M6 - 1mm Small Flat Washer

Part G x 4pcs



STEP 1A: Attach Left Headboard & Right Footboard Legs (Part 3) and Right Headboard & Left Footboard Legs (Part 4) to the Headboard and Footboard (Part 2) and the Left and Right Siderails (Part 1) using (16) M8 – 85mm Screws, (16) Large Lock Washers (Part D) and (16) Large Flat Washers (Part E). Tighten with M5 Allen Wrench (Part H)



STEP 1B: Attach Left Side Leg & Right Side Leg (Part 5) to the Left and Right Siderails (Part 1) using (4) M6 – 30mm Screws, (4) M6 – 1mm Small Lock Washers (Part F) and (4) M6 – 1mm Small Flat Washers (Part G). Tighten with M4 Allen Wrench (Part I).



STEP 2

STEP 2: Attach the Center Rails (Part 7) to the Headboard & Footboard (Part 2) using (4) 30mm Self-Tapping Screws (Part J)




STEP 3

STEP 3: Place rolled slats (Part 8) onto the Center Rails and Siderails.



STEP 4: Place the Center Legs (Part 6) under the Center Rail and unroll Support Slats until the first screw holes are visible. Attach the Support Slats to the Center Rails and Center Legs using (6) M6 – 50mm Screws, Tighten with M4 Allen Wrench

NOTE: Do not fully unroll support slats to begin. Once the first leg is attached, slowly unroll slats until the next screw holes are visible. Attach to center rails and legs one at a time until all 6 are attached.



STEP 5: Attach the slats (Part 8) to the side rail (Part 1) using (6) 30mm Self-Tapping Screws (Part J).