












BT-70172 PARTS


ASSEMBLY INSTRUCTION

(1)X1 	(6)X5 
(2)X1 	(7)X2 
(3)X1 	(8)X2 
(4)X1 	(9)X1 
(5)X1 	(10)X1 


①




②



③



④



⑤

