

























BT-90519H PARTS

ASSEMBLY INSTRUCTION

<p>(1)X1</p> 	<p>(7)X5</p> 	<p>①</p> 	<p>②</p> 
<p>(2)X1</p> 	<p>(8)X3</p>  <p>M8*20mm</p>	<p>③</p> 	<p>④</p> 
<p>(3)X1(L)X1(R)</p> 	<p>(9)X4</p>  <p>M8*45mm</p>	<p>(10)X3</p>  <p>8.5*17*1.5mm</p>	<p>⑤</p> 
<p>(4)X1</p> 	<p>(11)X4</p> 	<p>(12)X1</p>  <p>M6</p>	<p>(13)X1</p>  <p>M8</p>
<p>(5)X1</p> 	<p>(12)X1</p>  <p>M6</p>	<p>(13)X1</p>  <p>M8</p>	<p>(11)X1</p>  <p>M8</p>
<p>(6)X1</p> 	<p>(13)X1</p>  <p>M8</p>	<p>(11)X1</p>  <p>M8</p>	<p>(11)X1</p>  <p>M8</p>