


Thank you for your purchase!



6 Cubby 65" TV Stand for up to 80" TV's

ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.
DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

Customer Service Email: customerexperience@theubiquegroup.com | Phone: 866-552-2810

889142975946/889142975939/196861167782



Congratulations!

You just purchased a piece of happiness. At Ubique Group, we believe you can transform your spaces into the most inspired places with furnishings that are the perfect combination of form, function and style. As original innovators of online furniture retail, we offer the best selection of popular, contemporary styles at cool, comfortable prices. And, with decades of proven shipping and packaging expertise, our Extended Quality Checklist ensures a rewarding, hassle-free experience time and time again. It's just what you need to bring your vision to life.

Thank you & Enjoy!!

your friends at Ubique Group



LIKE IT!

*Share it on social
& Tell a friend!
#Spaces2Places*



LOVE IT!

*Write an online
product review
where purchased*



NOT SURE?

*Let us help!
Contact our
customer support.*

Have a question, concern or simply need a hand? Your satisfaction is our top priority. Contact us at 866-552-2810 or customerexperience@theubiquegroup.com. We're here to help!

Browse Our Branded Collections

There's something for everyone inside our family of brands.

FLASH
FURNITURE®

MERRICK | LANE

Taylor & Logan

Emma+Oliver®



BlackArc®



Visit www.theubiquegroup.com/brands or scan this code.



We pride ourselves on providing an excellent customer experience starting right here with your package and instructions. Everything you need should be right where you need it, so you can get to enjoying your new item ASAP. But despite our best efforts, sometimes "slips happen." If you need any support, from replacement parts to recommendations, please reach out to our wonderful customer support team at 866-552-2810 or customerexperience@theubiquegroup.com. We're here to help!

EVERY UBIQUE GROUP PRODUCT




Quality &
Durability Tested



Packaged
with Care



Shipped from
our U.S. Facility



Designed
for Easy
Assembly























Ethically
Sourced


Please visit <https://www.theubiquegroup.com/warranty> for complete warranty information.

Read this manual before using this product. Failure to follow the instructions and safety precautions in this manual can result in serious injury or death. Keep this manual in a safe location for future reference.



PARTS

(1)	Top Plate 	1	(11)	Left Front Fascia 	1	E	Screws 3.5*14 	8+1
(2)	Bottom Plate 	1	(12)	Right Front Fascia 	1	F	Back Panel Screws 3.5*20 	8+1
(3)	Left Side Panel 	1	(13)	Left Rear Fascia 	1	G	Shelf Holders 	12
(4)	Right Side Panel 	1	(14)	Right Rear Fascia 	1	H	Bottom Support Feet 	2
(5)	Inner Supports 	2	(15)	Middle Shelf 	1			
(6)	Right Inner Support Fascia 	1	(16)	Side Shelves 	2			
(7)	Left Inner Support Fascia 	1	A	Dowel Pegs 	18+1			
(8)	Front Upper Brace 	1	B	Screw-In Pegs 	32+1			
(9)	Upper Back Panel 	1	C	Cam Locks 	32+1			
(10)	Lower Back Panel 	1	D	Cam Lock Covers 	32+1			


STEP 1




STEP 2





STEP 3



STEP 4




STEP 5




STEP 5: Insert Cam Locks (Part C) into the Upper Front Panel (Part 8) and ensure the arrow side is facing outwards. Slide the Screw-In Pegs on the Left and Right Side Panels into the Cam Lock Receiver Holes in the Bottom Plate and Upper Front Panel (Part 8). Turn Cam Locks clockwise to tighten.

NOTE: Ensure grooves in side panels are at the back of the unit and align with the grooves in the Bottom Plate





STEP 6

STEP 6: Align the Lower Back Panel (Part 10) with the grooves in the Left and Right Side Panels and slide down until fully seated in the grooves of the Bottom Plate. Repeat steps with the Upper Back Panel (Part 9).




STEP 7





STEP 7: Ensure Cam Locks (Part C) are inserted in holes with open side facing outwards toward receiver hole for Screw-In pegs (Arrow Side). Slide Inner Supports (Part 5) onto Long Screw-In Pegs on the bottom plate. Turn the Cam Locks (Part D) clockwise to tighten.


Note: Ensure side of Inner Supports with 4 screw holes is facing the rear of TV Stand






STEP 8



STEP 8A: Ensure Cam Locks (Part C) are inserted in holes with open side facing outwards toward receiver hole for Screw-In pegs (Arrow Side). Place Top Plate (Part 1) onto the assembled frame. Confirm that all Screw-In Pegs and Dowel Pegs that were preassembled in STEP 1 are seated correctly. The groove on the underside of the Top Plate should be seated completely on the Upper Back Panel. Turn the Cam Locks (Part D) clockwise to tighten.




STEP 9




STEP 9: Insert Cam Locks (Part C) into holes with arrow side pointing outwards. Insert preassembled Screw-In Pegs on Left Fascia (Part 7) and Right Fascia (Part 6) into the Receiver Holes and turn Cam Locks clockwise to tighten.



STEP 10



STEP 10: Cover all Cam Locks with Cam Lock Covers (Part D)





STEP 11



STEP 11: Insert Shelf Holders (Part G) into holes at the desired height then place the Left & Right Shelves (Part 16) and the Middle Shelf (Part 15) onto Shelf Holders

STEP 12



STEP 12: Attach Upper and Lower Back Panels to the Inner Supports using (8) Back Panel Screws (Part F)

Quality and Safety Guidelines:

Please follow the static and dynamic weight capacity limits provided on this item.

If you are unsure of the weight capacities for this product, email us at customerexperience@theubiquegroup.com or call 866-552-2810.

Please use this item on a stable, level surface only. All TV Stand legs/feet should contact the flooring surface when in use. Do not use this item if any instability is detected.

For maintenance instructions and replacement parts, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.

Please do not sit, climb or stand on this item.

Do not slide the item when moving it.

To prevent crushing and pinching, keep hands and fingers away from all moving segments.

Please inspect this product regularly to make sure there are no damaged or worn parts. Also inspect to make sure all hardware is tightened correctly and securely. For inspection instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.

If any parts are damaged or worn, please stop using the product. Repair this product with manufacturer supplied parts only.

This item is intended for indoor use only.

Store indoors away from moisture. For additional storage instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.

Please visit www.theubiquegroup.com for our product warranty details or email us at customerexperience@theubiquegroup.com or call 866-552-2810.